

SECTION 6.10 CONTACTING THE FACTORY

If you have any questions concerning the service of the amplifier, you should call or write the amplifier service department at Henry Radio. If it ever becomes necessary to return the amplifier to the factory for repair you should first decide if you need to send the complete amplifier or just the RF chassis. Next pack the equipment in proper packing material to prevent shipping damage, include a short letter describing the exact problem, insure the package for the replacement value of the merchandise, and ship to our amplifier service department. Ceramic power tubes can be shipped installed in the RF chassis.

SECTION 7. DISASSEMBLING YOUR AMPLIFIER

The description of this procedure uses screw numbers which are shown on Figure 3. Refer to that drawing as necessary. CAUTION: Unplug the amplifier from the AC line before starting this procedure.

REMOVE THE TOP PANEL - Remove screws 2, 3, 6, and 7 and pull the top perforated painted panel off of the amplifier.

REMOVE THE BACK PANEL OF THE POWER SUPPLY - Remove screws 13, 14, 15, 16, 17, and 18 and pull the back panel away from the power supply section.

REMOVE CABLES - Disconnect all of the cables between the RF section and the power supply section.

REMOVE THE RF DECK - First remove the BAND, TUNE, and LOAD knobs from the front panel. Then remove two screws from the bottom of the back of the top wraparound. These are accessed by reaching up from the back of the power supply section. They are not shown on the diagram. Remove two screws from the area overhanging the front - screws 19 and 20. The RF deck should now slide out of the back of the wraparound. If you should need to send the RF section back for repair, you should send just the RF chassis, not the complete wraparound. Most service of the amplifier can be accomplished without any further disassembly. The front panel can now be accessed from the rear, the blower from top or bottom, and the power supply from the back.

REMOVE THE RF WRAPAROUND - Should you find it necessary to remove the top wraparound, remove the seven screws spaced around the inside bottom lip of the wraparound. They are reached through the top of the amplifier. Next disconnect the meter wiring harness and disconnect the wiring to the blower (below the RF wraparound). The cabinet will then lift off the power supply cabinet.

REMOVE THE POWER SUPPLY WRAPAROUND - The RF wraparound must be removed before you can remove the power supply wraparound. Carefully tip the power supply over to remove the four screws holding the painted wraparound to the bottom plate of the power supply. Tip the assembly back upright and then VERY CAREFULLY spread the back edges of the wraparound and slide it off the front of the frame.