

**Table 4-2
TROUBLE SHOOTING CHART (CONT'D)**

SYMPTOM	CASE	REMEDY
Amplifier always in transmit mode	Relay Control cable is shorted	Check center to shield for continuity: Re-do Relay Control cable
Amp will not load		Check Bandswitch setting Wrong antenna selected XMIT/STBY switch in STBY