

CAUTION

NEVER REMOVE /INSERT PLUG WHEN UNIT IS ON OR WHEN THE RF DECK AC LINE CORD IS CONNECTED TO AN AC POWER SOURCE



RF-OUT - For connecting the LK400/500 series linear amplifier to an antenna

RF-IN - For connecting to exciter RF output to the amplifier

KEY-OUT - GSK ONLY - hooks to the KEY-IN jack on a GSK transceiver

KEY-IN - GSK ONLY - station key, must be a push, hand key or a keyer

GSK VOX SWITCH - place in the GSK position when operating GSK CW

GROUND LUG - Attach to a good earth ground

FUSES - 2 fuses provided to protect each leg of the AC line

SERIAL NUMBER - Located on the model type identification sticker

AC LINE CORD - Connect to proper power requirements only

PAC-5 PLUG - LK800/L500 optional PAC-5 only. Connects the PAC-5 power transformer to LK500/L800